



INFINITY IF14 SUSPENSION MOUNT CHART

INFINITY IF14 サスペンションマウントチャート

INNER SHAFT MOUNTING WIDTH

インナーシャフト取り付け幅

Unit: mm
単位: mm

← Narrow 狭める		Wide 広げる →		Pin Height ピン高さ		
1	0.5	0.5	1			
38.5		40.0		41.5	6.0	1 ↑ Up 0.5 ↑ 上げる
	39.2	40.0	40.8		5.6	
38.5	39.2	40.0	40.8	41.5	5.3	0.5 ↓ 下げる 1 ↓ Down
	39.2	40.0	40.8		4.9	
38.5		40.0		41.5	4.5	
← Narrow 狭める		Wide 広げる →		Pin Height ピン高さ		
1	0.5	0.5	1			
43.0		44.5		46.0	6.0	1 ↑ Up 0.5 ↑ 上げる
	43.7	44.5	45.3		5.6	
43.0	43.7	44.5	45.3	46.0	5.3	0.5 ↓ 下げる 1 ↓ Down
	43.7	44.5	45.3		4.9	
43.0		44.5		46.0	4.5	
← Narrow 狭める		Wide 広げる →		Pin Height ピン高さ		
1	0.5	0.5	1			
44.5		46.0		47.5	6.0	1 ↑ Up 0.5 ↑ 上げる
	45.2	46.0	46.8		5.6	
44.5	45.2	46.0	46.8	47.5	5.3	0.5 ↓ 下げる 1 ↓ Down
	45.2	46.0	46.8		4.9	
44.5		46.0		47.5	4.5	

SKID ANGLE

スキッド角

Unit: degree
単位: 度

		FF / RF					
		← Down 下げる		Up 上げる →			
		1 (4.5)	0.5 (4.9)	(5.3)	0.5 (5.6)	1 (6.0)	
FR / RR	↑ 上げる	1 (6.0)	-2.0	-1.5	-1.0	-0.5	0.0
		0.5 (5.6)	-1.5	-1.0	-0.5	0.0	0.5
		(5.3)	-1.0	-0.5	0.0	0.5	1.0
	↓ 下げる	0.5 (4.9)	-0.5	0.0	0.5	1.0	1.5
	1 (4.5)	0.0	0.5	1.0	1.5	2.0	

FRONT TOE ANGLE

フロントトー角

Unit: degree
単位: 度

		FF				
		← Narrow 狭める		Wide 広げる →		
		1 (44.5)	0.5 (45.2)	46.0	0.5 (46.8)	1 (47.5)
FR	↑ 1 (44.5)	0.0	-0.5	-1.0	-1.5	-2.0
	Narrow 狭める 0.5 (45.2)	0.5	0.0	-0.5	-1.0	-1.5
	46.0	1.0	0.5	0.0	-0.5	-1.0
	広げる Wide 0.5 (46.8)	1.5	1.0	0.5	0.0	-0.5
	↓ 1 (47.5)	2.0	1.5	1.0	0.5	0.0

REAR TOE ANGLE

リアトー角

Unit: degree
単位: 度

		RF				
		← Narrow 狭める		Wide 広げる →		
		1 (38.5)	0.5 (39.2)	40.0	0.5 (40.8)	1 (41.5)
RR	↑ 1 (43.0)	3.0	2.5	2.0	1.5	1.0
	Narrow 狭める 0.5 (43.7)	3.5	3.0	2.5	2.0	1.5
	44.5	4.0	3.5	3.0	2.5	2.0
	広げる Wide 0.5 (45.3)	4.5	4.0	3.5	3.0	2.5
	↓ 1 (46.0)	5.0	4.5	4.0	3.5	3.0
		RF				
		← Narrow 狭める		Wide 広げる →		
		1 (43.0)	0.5 (43.7)	44.5	0.5 (45.3)	1 (46.0)
RR	↑ 1 (43.0)	0.0	-0.5	-1.0	-1.5	-2.0
	Narrow 狭める 0.5 (43.7)	0.5	0.0	-0.5	-1.0	-1.5
	44.5	1.0	0.5	0.0	-0.5	-1.0
	広げる Wide 0.5 (45.3)	1.5	1.0	0.5	0.0	-0.5
	↓ 1 (46.0)	2.0	1.5	1.0	0.5	0.0

